

**Gesamthubhöhe = Hubhöhe + ca. 1,2m Aufbauniveau**  
*Overall height = vertical outreach + approx. 1,2m installation height*  
**Hauteur totale = portee verticale + env. 1,2m hauteur de pose**

